

ASSEMBLY INSTRUCTIONS

Insulon® SAFETY GUARD

with Steinel HG 2320 E

Introducing a new way to reduce the risk of burn injury from hot air tools



1. This instruction is to install an Insulon Safety Guard onto a Steinel HG 2320 E heat gun with a 14mm reflector nozzle.







2. Remove the black plastic cover by rotating it counter-clockwise and separating it from the heat gun.









3. Place the Safety Guard on a flat surface and insert heat gun nozzle into the Insulon safety guard.

4. Apply downward force until the Safety Guard reaches the backstop.

Heat gun operators should always follow best practices for heat gun safety, including keeping the air inlet free from debris. Insulon Safety Guards are not intended to provide a tool-holding surface.